

Instructions for using Multi Dry

Instructions for use:

Multi Dry is activated by removing the protective foil. Direct contact with liquid-absorbing and products at risk of rusting (fabric, paper, metal) should be avoided for safety reasons (moisture transfer). For example, use a saucer while placing such products on a carpet. The degree of saturation (maximum 1.6 kg) can be determined by weighing.

Regeneration:

Multi Dry can be dried in an oven (not a microwave) or on a heater and reused. If using an oven for drying, place Multi Dry on a grating in the middle and set the oven temperature to about 175°C. Temperatures higher than this may damage the fabric of the bag. The drying process takes about 4-5 hours. In case of standard ovens, the cost of electricity is about 1 Euro (at 25 cents/kWh in accordance with DIN 44547). If Multi Dry is dried on a heater, the drying process takes several days.

Caution:

There is a possible risk of burn if the heated bag and especially the metal clamp is touched. For removing the bag from the oven, use oven mitts or hand gloves. Product contains salt - Avoid eye contact.

How it works:

Multi Dry absorbs the excess moisture from the air. This prevents fungus, rust, mould stains and musty odours. The moisture is absorbed by storage granules (no dripping system). Multi Dry can absorb up to 600 g of water. Multi Dry is odourless. Depending on the humidity and temperature, the dehumidification function is effective for 2-4 months for an area of about 35 m³. Multi Dry absorbs moisture even if the relative humidity level is very high of over 60 percent. The moisture is released back when the air is dry. It thus works only when the humidity is very high and has a compensating effect on the indoor climate when the humidity level changes.

