

Instructions for using Safe Dry

Instructions for using Safe Dry:

Take the black coloured dehumidifier pad and the indicator out of the foil bag. With the printed side facing outside, slide the indicator into the narrow slot on the back of the box such that the blue dot is visible in the window.

Replace the dehumidifier pad into the box and ensure that the fabric side through which the moisture enters, is on the side with the holes. Place Safe Dry in the protected space or compartment such that the holes are not covered. These help in absorbing the moisture better.

Compare the colour dot that is visible in the window now and then with the colour dots shown above and below it. If the colour of the dot in the window has turned pink, then it is time to weigh the dehumidifier pad. If the pad weighs more than 450 grams, you should replace or regenerate the dehumidifier.

Product contains salt, do not damage the fabric bag, avoid eye contact.

Regeneration:

Safe Dry can be dried on a heater for reuse. To do this, take the dehumidifier pad out of the box and place it on the heater with the foil side facing down. Safe Dry releases the absorbed moisture over a long duration back into the air, which may take days or weeks depending on the saturation level and the heating. A dry weight of about 330 g should be expected.

How it works:

Safe Dry is activated as soon as the foil bag is removed. It absorbs moisture from the air like a magnet, until the relative humidity falls below 60%. It thus prevents rust, fungus and musty odours. Up to 180 g of water are absorbed and stored. As soon as Safe Dry becomes saturated and the surrounding air is too humid, the humidity indicator changes its colour from blue to pink.

